

## LOG Crate instruction guide (item: PIN-37)

### TOOLS needed:

- ✓ Phillips screwdriver (or square drive)  
(Electric or hand powered)

### Components:

- **(2) side panels**
- **front and 1 rear panel**
- **wooden top**
- **(26) self-tapping screws (1 ½")**

1. Locate the **2 side panels**. Place them flat on the floor with the numbers (top edge of panel) up.
2. Locate the **front and back panels**. Place them flat on the floor (in the relative position for assembly) making sure the numbers on the top edge match up with the numbers on the top edge of the side panels.
3. Stand up **one side panel** and **the rear panel**. Double check that the numbers on the top edge match up. Locate the “black mark” on the rear panel and align the side panel to the “mark”. Attach the side panel to the rear panel using **(4) screws (2 on the top and 2 on the bottom)**.
4. **Repeat Step-3** with the other side panel.
5. **Repeat Step-3** with the front panel.
6. Attach the **solid panel top**. Place the finished side (visible side) of the top down on a padded surface (carpet or rug) to prevent any damage. Place the assembled panels on the wood top with the door panel on the end labeled “FRONT”. Align the panels with the corner marks and double check the panels are centered on the wood top.
7. Use the (10) remaining screws to attach the panels to the top. There should be (3) evenly spaced screws for each side panel and (2) screws for both the front and rear panels – 10 total.

Congratulations! Your assembly is complete!

